SS-GRX30/GRX30G/GRX30J/ RXD5/VX3A/VX3AG

SERVICE MANUAL

US Model
Canadean Model
SS-RXD5
E Model
SS-GRX30/GRX30G/GRX30J/ VX3A/VX3AG
Australian Model
SS-GRX30
Tourist Model
SS-GRX30J

Photo: SS-GRX30

- This set is the speaker system in MHC-GRX30/GRX30J/RXD5/VX3.

SPECIFICATIONS

Speaker system	3-way,3-unit, bass-reflex type
Speaker units	
Woofer:	15cm,cone type
Tweeter:	5cm,cone type
Super Tweeter:	2cm,ceramic type
Nominal impedance	6 ohms
Dimensions(w/h/d)	Approx. 220 × 340 × 265mm ($8^5/_8 \times 13^3/_8 \times 10^7/_{16}$ in)
Mass	Approx. 4.0 kg net per speaker (8 lb. 10 oz.)

Design and specifications are subject to change without notice

SPEAKER SYSTEM

MICROFILM

SONY®

EXPLODED VIEW AND PARTS LIST

NOTE:

- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- Abbreviations
  TH : Thai model



Ref. No.	Part No.	Description	Remarks
1	X-4950-905-1	PANEL ASSY, FRONT (GRX30,RXD5,VX3A)	
1	X-4951-414-1	PANEL ASSY, FRONT (GRX30G,GRX30J,VX3AG)	
2	X-4950-906-1	FRAME ASSY, GRILLE	
3	7-685-648-79	SCREW +BVTP 3 × 12 TYPE2 IT-3	
4	4-874-614-21	SCREW (4) (3.5 × 14), TAPPING	
5	4-216-141-01	DUCT PACKING (GRX30:EXCEPT TH,GRX30G,RXD5,VX3A,VX3AG)	
5	4-216-141-11	DUCT PACKING(GRX30:TH)	
5	4-216-141-21	DUCT PACKING(GRX30J)	
6	4-942-029-01	PACKING	

Ref. No.	Part No.	Description	Remarks
7	A-4411-438-A	CABINET ASSY, SPEAKER (GRX30:EXCEPT TH,RXD5,VX3AG)	
7	A-4411-558-A	CABINET ASSY, SPEAKER(GRX30:TH)	
7	A-4411-563-A	CABINET ASSY, SPEAKER(GRX30J)	
7	A-4411-581-A	CABINET ASSY, SPEAKER (GRX30G,VX3AG)	
8	1-790-746-11	CORD, CONNECTION	
SP1	1-529-240-11	SPEAKER (2CM)	
SP2	1-529-347-11	SPEAKER (5CM)	
SP3	1-529-242-11	SPEAKER (15CM)(RXD5)	
SP3	1-529-243-11	SPEAKER (15CM)(VX3A,VX3AG)	
SP3	1-529-244-11	SPEAKER (15CM)(GRX30,GRX30G,GRX30J)	

99C1644-1D
Printed in Japan ©1999.3
Published by Quality Assurance Dept. (Shinagawa)